



LockDown
incorporated

INFRASTRUCTURE SECURITY PRODUCTS

The LockOut Device

Installation Instructions



1

Remove lid and place on a level surface. Apply drill template directly over pre-drilled hole as shown.



4

Using T-handle, tighten bolt to base nut located in the frame of the handhole.



2

Place both feet side by side on drill guide as shown. Drill through lid with drill bit, repeating for other side of lid, if necessary.



5

Insert locking cylinder, turning key to secure to the sleeve of the LockOut Device. Remove key and secure.



3

Remove locking cylinder from LockOut Device and insert bolt into LockOut sleeve. Place sleeve and bolt in newly modified hole.



6

Remove a tabbed, adhesive backed protective cover from sheet provided. Fold back tab for easier removal and place cover over key hole. Follow up with screw-on metal cap and cover with sealant.

LockDown
incorporated

866-399-2512 • sales@lockdownsolutions.com • 2291 Plunkett Road, Conyers, GA