

The LockOut

Installation Instructions



1 Remove lid and place on a level surface. Apply drill template directly over pre-drilled hole as shown.



4 Using T-handle, tighten bolt to base nut located in the frame of the handhole.



2 Place both feet side by side on drill guide as shown. Drill through lid with drill bit, repeating for other side of lid, if necessary.



5 Insert locking cylinder, turning key to secure to the sleeve of the LockOut device. Remove key and secure.



3 Remove locking cylinder from LockOut and insert bolt into LockOut sleeve. Place sleeve and bolt in newly modified hole.



6 Follow up with screw-on metal cap and cover with sealant.