

THE LOCKGUARD DEVICE

Installation Instructions



Step 1
Hold LockGuard as shown



Step 5
Slide shackle through eyellet
in threaded rod




Step 2
Open padlock and insert
shackle into LockGuard



Step 6
Close and lock padlock



Step 3
Rotate padlock so that
shackle protrudes from side
of LockGuard



Step 7
LockGuard protects shackle
of padlock from being cut.